

Egg Cooker Care & Descaling Guide

The heating plate is the heart of your egg cooker, and the only part that needs real care. Five minutes a month keeps it cooking like new and stops scorch marks before they start.

After every use

Unplug and let the plate cool fully. Wipe it with a damp cloth — that is all a fresh plate needs. Wash the trays, lid and measuring cup in warm soapy water, or put them in the dishwasher. Never immerse the powered base in water.

The two-minute vinegar descale (monthly, or when scale shows)

Pour 2 tablespoons of white vinegar onto the cold heating plate. Let it sit for 2-5 minutes while the acid dissolves the mineral film. Wipe with a soft cloth or paper towel, then wipe once more with plain water. Stubborn brown spots: make a paste of baking soda and water, rub gently, and wipe clean. Never use steel wool or scouring pads on the plate.

Habits that prevent damage

Hard water scales faster — if your tap water is very hard, use filtered water in the cup. Always pierce eggs before cooking; a burst egg bakes residue onto the plate. Store the trays inside the unit with the cord wrapped, lid ajar, so no moisture stays trapped.

A free ZoxDeal bonus for readers of our DASH Deluxe egg cooker review. Honest kitchen advice at zoxdeal.com.