

Indoor Camera Setup Guide

For the Ring Pan-Tilt Indoor Cam 2K (plug-in, 2.4GHz Wi-Fi).

Placement (one camera, whole room)

Put it in a corner, slightly above eye level, facing the open room.
Keep it near a power outlet. It is plug-in only, not battery powered.
Avoid pointing it straight at a bright window. Backlight washes out faces.

Home position

In the Ring app, pan and tilt to your preferred default view.
Save it as the home position. The camera returns there after events.
Re-check the view at night. Infrared video looks different from daylight.

Motion zones (fewer false alerts)

Draw zones only over doorways, walkways, and pet areas.
Exclude TV screens and ceiling fans. Both trigger motion alerts.
Start on medium sensitivity, then adjust after a few days.

Privacy settings

Slide the built-in shutter closed when you want the room fully private.
The shutter disables the camera AND the microphone in one slide.
Set Device Modes (Home / Away) so recording matches your routine.

Subscription check

Live view and motion alerts work without a plan.
Recorded video history needs a Ring Protect plan. Check live pricing.
Confirm your plan covers this camera before relying on playback.