

Nugget Ice Maker Care Guide

Cleaning, descaling and daily habits that keep pebble ice tasting clean

A ZOXDEAL EXCLUSIVE BONUS

The Weekly Routine (10 minutes)

- Empty the ice basket and wipe it with a soft, damp cloth.
- Drain any standing water from the tank; refill with fresh water.
- Wipe the exterior and the water-level window so you can read levels.
- Leave the lid open for 15 minutes after emptying to air-dry seals.

The Monthly Deep Clean

- Run the self-clean cycle (on Silonn models: hold ICE/CLEAN ~5 sec).
- For scale: fill the tank with a 1:10 white-vinegar and water mix,
- run one cleaning cycle, then drain completely.
- Run TWO plain-water cycles afterwards so no vinegar taste remains.
- Remove the top cover where the design allows and wipe the auger area.
- Dry everything for at least a few hours before the next batch.

Water Quality Rules

Filtered or distilled water makes clearer, better-tasting nugget ice and dramatically slows mineral scale. Hard tap water is the number-one cause of slow production, cloudy ice and off tastes in countertop ice makers.

- Never use hot water in the tank — room temperature only.
- If ice output drops, descale BEFORE assuming the machine is broken.
- In hard-water areas, descale every 2-3 weeks instead of monthly.

Troubleshooting Quick Table

The five problems almost every nugget ice maker owner meets

A ZOXDEAL EXCLUSIVE BONUS

Ice Melts or Clumps in the Basket

Normal, not a defect: the storage basket on countertop nugget machines is insulated, not refrigerated. Meltwater drains back and gets recycled, but for ice you plan to keep, transfer it to a freezer bag and freeze it solid.

Machine Sounds Louder Than Expected

Nugget machines use a compressor plus an auger, so a steady hum and occasional scraping sounds are normal. Place the unit on a solid, level surface with a few inches of ventilation space on all sides to cut vibration noise.

Production Slows Down

- Room too warm? Output ratings assume ~70°F / 21°C ambient.
- Vents blocked by walls or other appliances? Give it breathing room.
- Scale build-up? Run the descaling routine from page 1.

Ice Tastes or Smells Off

- Deep clean + two plain-water rinse cycles (page 1).
- Replace tank water daily if the machine sits unused.
- Check the drain plug area for trapped meltwater and wipe dry.

Storing the Machine (1+ Weeks Unused)

- Drain all water, run one self-clean cycle, drain again.
- Dry the tank and basket fully; store with the lid open.
- Before the next use, run one plain-water cycle and discard that ice.