ANC Earbuds Fit & Care Guide

QCY MeloBuds Pro — get the best sound, ANC, and battery from day one.

1. Find your fit

Try every ear-tip size in the box. The right tip seals the ear canal without pressure. A good seal is what makes ANC work — without it, bass drops and noise leaks in. If the bass sounds thin, try a larger tip before you blame the earbuds.

2. Use the ANC modes the smart way

The MeloBuds Pro cycles ANC off, Transparency, then ANC on. Tap the earbud to step through them. Use ANC on for buses, planes, and offices. Use Transparency when you need to hear traffic or announcements. You cannot remove the ANC-off step, so learn the tap order and it becomes second nature.

3. Set up LDAC for the best sound

On Android, open the QCY app and turn on LDAC for Hi-Res audio. In quiet rooms it sounds clearly better. In crowded stations it can stutter — if it does, switch back to AAC in the app. Stable sound always beats a stuttering Hi-Res stream.

4. Battery habits that pay off

Put the earbuds back in the case after every use. A 10-minute top-up gives hours of playback. Charge the case over USB-C, or drop it on any Qi wireless charger. Avoid leaving the case fully empty for weeks — lithium batteries age fastest at 0%.

5. Clean them weekly

Wipe the ear tips with a dry cloth. Clear the mesh gently with a soft brush — never push wax into the driver. Wash silicone tips with mild soap and water, then dry them fully before use. Keep the case out of dust and pockets full of lint.

6. Quick troubleshooting

Problem	Fix
One earbud is quiet	Check the tip seal, clean the mesh, re-pair.
LDAC stutters	Switch to AAC in the app in crowded places.
ANC feels weak	Try a larger tip; check the seal.
Touch taps mis-fire	Tap lightly on the flat face, not the edge.
Case will not charge	Clean the USB-C port and the case contacts.

Made by ZoxDeal as a free bonus for readers of the QCY MeloBuds Pro review. Specs change with firmware updates — check the QCY app for the latest features.